

【 Emergency call unit operational instructions】



When a red button 【①】 is pressed, buzzer sound rings, and a red light 【②】 lights up. reply at the energy centre or the guard and call by a microphone 【③】 .
When replying , light 【⑤】 of the lower part of a emergency call unit camera 【④】 lights up.
A reply can't be completed by emergency call unit.

【Emergency call unit general view】



【Emergency call unit operating part upper part】



【The emergency call unit operating part lower part】




点灯中は通話できません
(他の通報装置と通話中です)
No Connection if lamp is lit
(The Line is busy)

マイク



mic

この ボタンを押すと
守衛所へつながります
Press this button to speak to the guard



ボタンのランプがきえているときはつかえません
No Connection if lamp is not lit